## Standard Vinyl Strips are "do-it-yourself," high quality and economical.

## Our Customers Write...

We replaced our damaged door strips with your vinyl ones. They are very durable and make the barn weather resistant. We like the high-quality products you offer, along with the fantastic service we receive.

-Wesley Bourcy, Cape Vincent, NY

Fill in the blanks





## Vinyl Strip doors protect from noise, heat, cold, humidity, dust and drafts. It's easy to order and install.

i iii iii ciic biaiiitsi					
I. Linear Footage Factor:					
Determine your door's linear footage factor using the chart below.					
First select the material width.					
<ul> <li>Next, follow the row across to the column representing</li> </ul>					
the overlap percentage you have decided on. The number					
in the box is your linear footage factor.					
2. Height of opening: (round up measurement to next					
full foot, i.e., 15'6" rounds to 16').					
3. Width of opening:(round up measurement to next					
full foot, i.e., 19'4" rounds to 20').					
4. Multiply the door width from step 3 by the linear footage factor					
from step 1. The result is the number of strips required.					
Door width: x Linear Footage Factor:					
= Number of strips required:					

5. To determine the actual linear feet of strip, multiply the number of strips required from step 4 by the height of the door from step 2:

6. Finally, select your mounting hardware.

Example: Medium traffic exterior doorway in a northern Minnesota warehouse. The following steps correspond to the ordered checklist above. For this heavy-duty application, we selected 12"W, standard offset double-ribbed vinyl strips.

- 1.1.5 linear footage factor, 12" strips with a 67% overlap.
- 2. 16' (i.e., the door is actually 15'6" rounded up to 16 ft.).
  3. 20' (i.e., the door is actually 19'4" rounded up to 20 ft.).
- 4. 1.5 linear footage factor  $\times$  20' width of door = 30 strips needed.
- 5.30 strips required  $\times$  16' height of door = 480 linear ft.

The door requires 480 linear ft. of 12"W offset double-ribbed vinyl strips. Now just decide on mounting hardware.

6. Two 8' Universal Strip Door Mounting Kits will mount strips along the 16' of door's width. Strips will mount directly under the header and will not interfere with automatic overhead doors.



Determining Linear Feature							
Determining Linear Footage							
DESIRED	OVERLAP PERCENTAGE						
WIDTH	25%	33%	50%	67%	75%	100%	
6"	-	2.4	-	3	ı	4	
8"	1.75	-	2	-	2.5	3	
12"	_	1.2	1.35	1.5	-	2	

- Outstanding transparency. "See-thru" quality.
- Manufactured of flame resistant compounds.
- Extruded with rounded edges.